INSTALLATION INSTRUCTIONS WASATCH CONFIGURATIONS

1. Take a backup of your current software installation
2. You need the latest version of the Wasatch software to run our configurations. You can download it on www.wasatch.com/install.html.
3. You can only install the latest version if you have an active support contract with Wasatch. If this is not the case, we can activate it for you. Send a mail to contact@starttosublimate.com with the serial number of your dongle, so we can send you a quote.
4. Open your Wasatch application
5. In 'Unit 1' select the printer you want to configure (ex: Epson Surecolor F6200
6. Choose as 'Physical Connection' the fixed IP address of your printer
7. Choose the correct .ZIP file in the download section on the Start To Sublimate website
8. Unzip this folder and copy it in C:\wwrip75\Configurations\epsonF6200 (or the folder of your selected printer)
9. Go back to the Wasatch application and select now in the dropdown menu 'Imagaing Configuration' the name you just copied

REMARKS:

- If you receive an error message that the configuration is damaged, this means that you have not installed the latest version and/or build of Wasatch. Go back to step 2 & 3.
- Do not change the name of the folder. This will result in a damaged imaging configuration
- Always use a network connection as physical connection. USB cables can cause problems
- Double check if the MIRROR checkbox is ON
- Make a backup of all your settings on a USB or external hard disk.

If you have problems or other questions, please fill in the technical form on
www.starttosublimate.com/support